

**EP500**

**Advanced**

**ATEX Electropneumatic Positioner**

Installation and Maintenance Instructions

---

---



1. Safety information
2. Technical information
3. Installation
4. Commissioning
5. Maintenance
6. Spare parts
7. Fault finding
8. Approvals

# 1. Safety information

Safe operation of these products can only be guaranteed if they are properly installed, commissioned, used and maintained by qualified personnel (see Section 1.11) in compliance with the operating instructions. General installation and safety instructions for pipeline and plant construction, as well as the proper use of tools and safety equipment must also be complied with.



**WARNING:** The maximum process fluid temperature must be suitable for use if the unit is to be used in any potential explosive atmosphere. For the device maintenance in a potentially explosive atmosphere, we recommend the usage of tools which do not produce and/or propagate sparks.

## 1.1 Intended use

Referring to the Installation and Maintenance Instructions, product markings and Technical Information Sheet, check that the product is suitable for the intended use/application. These products comply with the requirements of the Directive 2014/34/EU (ATEX) for the use of equipments in potentially explosive atmospheres.

## 1.2 Access

Ensure safe access and if necessary a safe working platform (suitably guarded) before attempting to work on the product. Arrange suitable lifting gear if required.

## 1.3 Lighting

Ensure adequate lighting, particularly where detailed or intricate work is required.

## 1.4 Hazardous liquids or gases in the pipeline

Consider what is in the pipeline or what may have been in the pipeline at some previous time. Consider: flammable materials, substances hazardous to health, extremes of temperature.

## X 1.5 Hazardous environment around the product

Consider: explosion risk areas, lack of oxygen (e.g. tanks, pits), dangerous gases, extremes of temperature, hot surfaces, fire hazard (e.g. during welding), excessive noise, moving machinery. The positioner suitable for installation in Zone 1 or Zone 2 ( Gas ) Zone 21 or Zone 22 ( Dust ) according to the Atex rating reported in the following. The positioner shall not be used in zone 0.

## 1.6 The system

Consider the effect on the complete system of the work proposed. Will any proposed action (e.g. closing isolation valves, electrical isolation) put any other part of the system or any personnel at risk?

Dangers might include isolation of vents or protective devices or the rendering ineffective of controls or alarms. Ensure isolation valves are opened and closed progressively to avoid system shocks.

## 1.7 Pressure systems

Ensure that any pressure is isolated and safely vented to atmospheric pressure. Consider double isolation (double block and bleed) and the locking or labelling of closed valves. Do not assume that the system has depressurised even when the pressure gauge indicates zero.

## 1.8 Temperature

Allow time for temperature to normalise after isolation to avoid the danger of burns.

## **1.9 Tools and consumables**

Before starting work ensure that you have suitable tools and/or consumables available. Use only genuine Spirax Sarco replacement parts.

## **1.10 Protective clothing**

Consider whether you and/or others in the vicinity require any protective clothing to protect against the hazards of, for example, chemicals, high /low temperature, radiation, noise, falling objects, and dangers to eyes and face.

## **1.11 Permits to work**

All work must be carried out or be supervised by a suitably competent person. Installation and operating personnel should be trained in the correct use of the product according to the Installation and Maintenance Instructions.

Where a formal 'permit to work' system is in force it must be complied with. Where there is no such system, it is recommended that a responsible person should know what work is going on and, where necessary, arrange to have an assistant whose primary responsibility is safety.

Post 'warning notices' if necessary.

## **1.12 Handling**

Manual handling of large and/or heavy products may present a risk of injury. Lifting, pushing, pulling, carrying or supporting a load by bodily force can cause injury particularly to the back. You are advised to assess the risks taking into account the task, the individual, the load and the working environment and use the appropriate handling method depending on the circumstances of the work being done.

## **1.13 Residual hazards**

In normal use the external surface of the product may be very hot. If used at the maximum permitted operating conditions the surface temperature may reach temperatures in excess of 167 °F..

Many products are not self-draining. Take due care when dismantling or removing the product from an installation (refer to 'Maintenance instructions').

## **1.14 Freezing**

Provision must be made to protect products which are not self-draining against frost damage in environments where they may be exposed to temperatures below freezing point.

## **1.15 Disposal**

Unless otherwise stated in the Installation and Maintenance Instructions, this product is recyclable and no ecological hazard is anticipated with its disposal providing due care is taken.

## **1.16 Returning products**

Customers and stockists are reminded that under EC Health, Safety and Environment Law, when returning products to Spirax Sarco they must provide information on any hazards and the precautions to be taken due to contamination residues or mechanical damage which may present a health, safety or environmental risk. This information must be provided in writing including Health and Safety data sheets relating to any substances identified as hazardous or potentially hazardous.

# 2. General product information

## 2.1 Introduction

The EP500 is a 2 wire loop powered positioner requiring a 4-20 mA control signal, and is designed for use with linear pneumatic valve actuators. The positioner compares the electrical signal from a controller with the actual valve position and varies a pneumatic output signal to the actuator accordingly. A mounting kit is supplied to suit all pneumatic actuators compliant with the NAMUR standard.

## 2.2 Operating principle

The current signal (1) flows in the coil (2) and generates a magnetic field which attracts the flapper (3) tapping the nozzle (4). As a consequence of this the pressure inside the actuator increases and the valve moves. When the valve stem (5) moves it generates through the feedback lever (6) and the feedback spring (7) a negative feedback which moves the flapper away from the nozzle and stops the valve movement.

Changes in the current signal will induce changes in the valve positioning.

This mechanism will build a linear correspondence between the current signal and the valve position expressed in percentage of the valve stroke. The valve opening at 4 mA and at 20 mA can be adjusted manually as illustrated in Figure 1.

### Key:

- 1 = Current signal
- 2 = Coil
- 3 = Flapper
- 4 = Nozzle
- 5 = Valve stem
- 6 = Feedback lever
- 7 = Feedback spring
- 8 = Pneumatic relay
- 9 = Pneumatic actuator
- 10 = Span lever




Fig. 1 Functional schematic

## 2.3 Applications

The EP500 can be used with any actuator that conforms to NAMUR, this includes all of the following Spirax Sarco pneumatic actuators:

- PN1000 and PN2000 series
- PNS3000 and PNS4000 series
- PN9000 series
- TN2000 series

## 2.4 Materials

Part	Material	Finish
Case and cover	Die cast aluminium	Anti-corrosive paint to RAL9006

## 2.5 Technical data

Input signal range	4-20 mA (split range minimum amplitude 4 mA)
Input resistance	292 Ω
Air supply	1.4 to 6.0 bar (regulate 5 to 10 psi above actuator spring range)
Air quality	Air must be free of water, oil and dust
Output pressure	0 to 100% supply pressure
Actuator stroke	10 mm to 100 mm
Action	Single acting / fail vent
Operating temperature	-20 °C to +75 °C
Air flow	3.20 Nm <sup>3</sup> /h @ 1.4 bar
Steady state air consumption	0.1 Nm <sup>3</sup> /h @ 1.4 bar
Air connections	¼" NPT female
Sensitivity	≤0.2% F.S. (Full Scale)
Histerisis	≤0.4% F.S.
Linearity	≤1.0% F.S.
Repeatability	≤0.5% F.S
Electrical connections	Cable gland M20 internal terminals for conductors from 0.5 to 2.5 mm <sup>2</sup> wire
Degree of protection	IP65
Characteristic	Linear
Shipping weight	2.35 kg
Material (housing and cover)	Die-cast aluminium anti-corrosion paint RAL 9016
Atex rating	II 2G Ex d mb IIC T6 Gb II 2D Ex tb mb IIIC T76oC Db II 2G Ex ia IIC T6 Gb II 2D Ex ia IIIC T76oC Db
Ex ia circuits parameters	Ui=30V Ii=110mA Pi=0.82W Li=0 Ci=0

# 3. Installation

**Note:** Before starting any installation observe the 'Safety information' in Section 1.

This document is provided as a guide and it is recommended that it is read thoroughly prior to installation. Also refer to the separate Installation and Maintenance Instructions for the control valve and actuator.

## 3.1 Location

The positioner should be mounted in sufficient space to allow opening of the cover and provide access to connections. When fitting to an actuator, ensure the positioner will not be exposed to an ambient temperature outside the range -20 °C to +75 °C. The positioner enclosure is rated to IP65. Connection of air supply pressure (1.4 to 6 bar g) and control signal (4 - 20 mA) should be considered prior to choice of location.

## 3.2 Connecting up

### 3.2.1 Pneumatic connections

**Warning:** Air supply must be dry, oil and dust free. Dirty air supply may damage the product and invalidate warranty.

For best performance, set the air supply pressure to about 0.5 bar g above the pressure required to fully travel the actuator.

Check all connections for leaks. Please note however that the EP500 bleeds air in normal operation at a rate of approximately 0.1 Nm<sup>3</sup> / hour at 1.4 bar supply pressure.

Pneumatic connections are located at the right hand side of the positioner and are identified as follows 'SUPPLY' and 'OUT':

SUPPLY - Air supply - 1.4 bar g to 6 bar g, depending upon required actuator spring range.  
OUT - Output signal to the actuator.

Connections are ¼" NPT female. Interconnection between the positioner and the actuator should be at least 6 mm OD tube.

### 3.2.2 Electrical connections

The EP500 only requires a 4-20 mA signal. Remove the front.

**Note:** Ensure resistance from earth post to local earth (e.g. pipework) is less than 1 Ohm. Connection to the unit is through the M20 cable gland (as supplied), which when used with suitable cable will ensure the IP65 protection rating. Appropriate conduit connections may be used instead.

Connect conductors (0.5 to 2.5 mm<sup>2</sup>) to the terminal blocks and earth noting the polarity +/- . Refer to the table below for the suitable connection:

Action	4-20 mA polarity	EP500 terminal block
Direct	+	Red
	-	Black
Reverse	+	Black
	-	Red

**Direct action** - the air pressure increases when current signal increases and vice versa.

**Reverse action** - the air pressure decreases when the current signal increases and vice versa.

### X 3.2.3 Electrical connection for ATEX equipment

When the positioner is installed in hazardous areas special precautions must be taken. In case the explosion proof protection system is used: a fuse of 100 mA should be inserted in the circuit to provide protection against overcurrent as indicated in the drawing here below:




Fig. 2

In case the intrinsically safe protection system is used, voltage and current should be limited using a suitable barrier as indicated in the drawing here below:




Fig. 3

The barrier shall be chosen in accordance with intrinsic safety parameters declared for the EP500 positioner. Please refer to the technical sheet.

### 3.3 Mounting the positioner onto the actuator

The EP500 can be attached onto any type of valve and actuator conforming to NAMUR standards. The unit can be attached in the traditional centered position (Figures 4 and 5) in line with the actuator central axis or side mounted (Figures 6 and 7) to enable the operator to view frontally the stem of the valve.

#### Step 1

Attach the mounting bracket on one of the two positions shown below with the two M8 x 14 screws and washers.

#### Centre mounting



Fig. 4



Fig. 5

#### Side mounting




Fig. 6




Fig. 7

## Step 2

Using the 2 off M6 pan head screws, securely attach the 'T' shaped sliding pin holder to the valve actuator coupling block (Figure 8).

Fig. 8



Depending on the travel of the valve actuator and depending on the actuator yoke, apply a medium strength thread locker to the sliding pin and screw into the correct hole on the sliding pin holder and tighten. Use Figure 9 and Table 1 to determine the correct hole to use.




Fig. 9 Feedback lever fulcrum

Pin

## Table 1

The 'T' bracket can be moved towards the right or towards the left. This allows the adjustment as displayed below between the lever fulcrum and the pin:

Actuator stroke (mm)	Distance between feedback lever fulcrum and pin	Feedback lever
20	70	
30	70	
50	80	
70	80	
75	115	
100	115	

### Step 3

Attach the bracket to the actuator with the screw M8 x 20 with washers (Figure 10). Take care to insert the feedback pin in the slot of the feedback lever while you attach the positioner (Figure 11)




Fig. 10





Fig. 11

## Step 4

Air connections and electrical connections.



Insert the electric cable (4 to 20 mA), connect to the appropriate terminals and screw the cap.

## X Step 5


Fig. 14

After properly completing the wiring and before retightening the M50 Ex d cap, make sure that the M5 x 10 screw - Ex d locking cap is fully tightened, using a 4 mm allen key.




Fig. 15

After manually screwing the cap Ex d M50 cap, loosen the Ex d locking cap M5 x 10 screw, using a 4 mm allen key, by exerting a slight pressure between the screw head and EX d cap. This operation is to prevent accidental unscrewing of the Ex d cap.



## Step 6

Open the lid of the positioner.



The positioner will be in this configuration: the spring of the SPAN disconnected.

Fig. 16

Turn the ZERO dial (the green one), until the valve is opened at 50%

Slightly loosen the M8 x 14 screw that is connecting the mounting bracket on to the actuator yoke. Move the positioner and bracket upwards or downwards, so that the feedback lever is horizontal, then tighten the M8 x 14 screw to the required position.





Fig. 17



**Fig. 18 Correct placement**




**Fig. 19 Incorrect placement**

1. Loosen the allen screw (black), with a 4 mm key

2. Rotate the lever to the vertical position

3. Tighten the allen screw (black), with a 4 mm key



**Fig. 20**

4. Hook the spring to the respective pin on the SPAN

# 4. Commissioning


## 4.1 Set the valve action

Firstly, with reference to Figure 21, determine the action that is relevant to your application.

**To change the slider** turn the red gear until the slider is positioned into the correct half of the span arm.

\* **Please note** that the arrow illustrates the stem movement direction when the input control signal increases.

### Direct action



### Reverse action (inverse polarity input signal)




Fig. 21

## 4.2 Set sensitivity

Xp regulation




Fig. 22

**We recommend not to change the Xp regulation until you familiarise with the product and with this regulation.**

To increase positioner sensitivity close the adjusting screw, to decrease sensitivity open the screw. **Do not** open the screw beyond the mechanical lock.


Xp closed means the positioner is very reactive and consuming a small amount of air. However on small valves this could result in valve hunting. In this case, unscrew slightly (in steps of 1/8 turns) the Xp screw, until the oscillation disappear.

Xp opened means that the unit is less reactive wastes more air, but is more stable.

**Note:** Adjustment of the Xp % screw causes a change of positioner 'zero' point, and it is therefore important to repeat the zeroing and travel setting procedures after any changes.

**Once the positioner has been mounted and connected up, proceed as follows:**

### 4.3 Calibration



**Fig. 23**

Feed the EP500 with a current input of 4 mA, turn the ZERO (green knob), till it reaches the value of the desired pressure and the valve opening reaches the starting position.

Feed the EP500 with an input current of 20 mA, turn the SPAN (red knob), until it reaches the desired pressure and the valve is fully opened or reaches the desired opening percentage according to the application requirements.

In order to refine the values of ZERO and SPAN repeat the operation more times till the required configuration is achieved.

#### **Split range operation**

EP500 may be split ranged to sequentially actuate two valves from one control signal e.g.:

**Valve 1** Set 4 - 12 mA,

**Valve 2** Set 12 - 20 mA.

Split ranging is achieved by adjustment of the zero and travel settings as described above.

### 4.3 Damping screw




Fig. 24

The calibration of damping screw will be carried out during plant operation, it has the purpose of limiting, if necessary, the speed of the pneumatically operated valve: the reduction of the air flow to the servo motor may introduce delays in the positioning of the valve for which it is recommended for use only in the case of servomotors of small capacity and when there is a major tendency to cyclical swings.




Fig. 25

#### Attention

Do not unscrew behind this limits. The air pressure in the piping might push out the screw.

# 5. Maintenance

## 5.1 Regular maintenance

1. Drain any build-up within the air supply filter set as impurities such as oil, water and dirt will cause inconsistent operation.
2. Ensure air supply is at the correct pressure (see Section 3.3.2 and refer to the actuator TI).
3. Make visual checks to ensure that the valve is operating correctly.

- X** 4. Wipe the unit with a damp cloth or antistatic products

## 5.2 Corrective maintenance

### 5.2.1 Removal and cleaning of sensitivity adjuster (see Figure 26):

- Loosen and remove the lock.
- Note setting then remove the sensitivity screw.
- Wash the adjuster with solvent, checking the condition of the cone and ensuring that the hole is clear.
- Dry with clean compressed air to ensure that there is no remaining contaminants.
- Refit the the cleaned adjuster and unscrew it  $\frac{1}{4}$  turn from its stop.




Fig.26

- Refit the lock to touch the adjuster top and secure it with the lock-nut.
- Set the sensitivity see Step 2, Section 4, Commissioning.
- Reset zero and span if required.

# 6. Spare parts

The spare parts available are detailed below. No other parts are available as spares.

## Available spares

	Full scale 0 - 2 bar	1
Gauges	Full scale 0 - 4 bar	2
	Full scale 0 - 7 bar	3
	<hr/>	
Back plate and gasket		4
Amplifying relay set		5
Gasket set	<b>Note:</b> Spare parts 5, 6 and 7 are not visible in Figure 27.	6
Mounting kit		7

## How to order spares and accessories

Always order spares by using the description in the column headed 'Available spares' and a description of the product.

### Example:

1 off Gauge 0-2 bar for a Spirax Sarco EP500 electropneumatic positioner.




Fig. 27

## **Product return procedure**

Please provide the following information with any equipment being returned:

1. Your name, Company name, address and telephone number, order number and invoice and return delivery address.
2. Description of equipment being returned.
3. Description of the fault.
4. If the equipment is being returned under warranty, please indicate:
  - i. Date of purchase
  - ii. Original order number

### **Please return all items to your local Spirax Sarco branch.**

Please ensure all items are suitably packed for transit (preferably in the original cartons).

# 7. Fault finding

## Output pressure too low or zero

Cause	Remedy
a. No control signal	a. Restore mA signal
b. Low air supply pressure	b. Verify actuator air pressure requirement
c. Clogged or dirty sensitivity adjuster	c. Clean adjuster see Section 5.2.1
d. Incorrect set-up	e. Recalibrate
e. Damaged pneumatic actuator or piping	f. Verify replace as necessary

## Output pressure too high

Cause	Remedy
a. Sensitivity adjuster open too far	a. Recalibrate

## Actuator movement too slow

Cause	Remedy
a. Low air supply capacity	a. Check supply capacity and pipe sizes

## Actuator failing to close

Cause	Remedy
a. Output pressure too low	a. Refer to previous fault
b. Incorrect zero point	b. Recalibrate
c. Valve/actuator coupling incorrect	d. Reset (refer to valve/actuator IMI's)
d. Actuator too small	e. Fit correct actuator

## Actuator failing to fully open valve

Cause	Remedy
a. Output pressure too low	a. Refer to previous fault
b. Incorrect travel adjustment	b. Recalibrate see
c. Valve / actuator coupling incorrect	d. Reset (refer to valve / actuator IMI's)
d. Actuator too small	e. Fit correct actuator

## Hunting

Cause	Remedy
a. Incorrect controller set up (P, I, and D)	a. Verify and adjust according to process requirement
b. Sensitivity orifice closed too far	b. Adjust by opening sensitivity screw
c. Excessive valve friction	c. Verify and maintain as valve IMI
d. Control valve over-sizing	d. Verify operating conditions against valve capacity

**Note:** The effects of hunting caused by valve over-sizing or unstable process conditions can be reduced by adjustment of damping.

# 8. Approvals

spiraxsarco.com/global/italy



## DICHIARAZIONE DI CONFORMITA' UE - N°RDS002 Rev.01 EU DECLARATION OF CONFORMITY - N°RDS002 Rev.01

Spirax-Sarco S.r.l. Via per Cinisello 18,  
20834 - Nova Milanese (MB) Italia,  
Con la presente dichiara che il prodotto sotto descritto, è stato sottoposto alla procedura di fabbricazione basata sulla Assicurazione della Qualità del Processo di produzione come da allegato IV della Direttiva Europea 2014/34/UE (ATEX).  
Hereby declares that the product below has been performed by fabrication procedure based on Quality Assurance Production Process as according to attach IV of European Directive 2014/34/EU (ATEX).

II 2G Ex d mb IIC T6 Gb  
II 2D Ex Ib mb IIC T76°C Db  
II 2G Ex ia IIC T6 Gb  
II 2D Ex ia IIC T76°C Db

**POSIZIONATORE ELETTROPNEUMATICO EP500 Advanced**  
**ELECTRO PNEUMATIC POSITIONER EP500 Advanced**

*Lo strumento è destinato ad essere impiegato in atmosfere potenzialmente esplosive  
È stato progettato, costruito ed ispezionato secondo le seguenti normative*

*The instrument is designed for use in potentially explosive atmospheres  
have been designed, manufactured and inspected according to the followings standards*

EN 60079-0 : 2012 , EN 60079-18 : 2009 , EN 60079-1 : 2007, EN 60079-31 : 2009 , EN 60079-11 : 2012

che ottemperano ai requisiti richiesti dalla  
which comply with the requirements requested by

**Direttiva Europea 2014/34/UE (ATEX)**  
**European Directive 2014/34/EU (ATEX)**

Fascicolo tecnico n° Technical Dossier n°	Numero dell'attestato UE di tipo EU type certificate number	NB (Ente notificato) NB (Notified Body) ICIM S.p.a. Via Don Enrico Mapelli 75 20099 Sesto San Giovanni Milano n° notifica 0425
RDS002	0425 15 ATEX 002822-00 X	

Garanzia Qualità Produzione Quality Production Warranty	Numero di certificato di sistema Quality System Quality Certificate Number	NB (Ente notificato) NB (Notified Body) ICIM S.p.a. Via Don Enrico Mapelli 75 20099 Sesto San Giovanni Milano n° notifica 0425
Allegato IV Attachment IV	0425 ATEX 007894-00	

Nova Milanese, 25-11-2016

Il Direttore di Stabilimento

Plant Manager  
Eduardo Uslenchi

Sede legale: Via per Cinisello, 18-20054 Nova Milanese (MI)  
Iscrizione Reg.Imprese e Cod.Fisc. 06527950585 - Iscrizione R.E.A. Milano 1172330 - Partita Iva 11339630151



SGQ N° 004 A SSI N° 008 G  
 SCR N° 003 D PRO N° 004 B  
 SCR N° 003 F SUP N° 042 E  
 PRS N° 001 C SGE N° 005 H

Membro degli Accordi di Mutuo Riconoscimento EA, IAF e ILAC  
 Signatory of EA, IAF and ILAC Mutual Recognition Agreements



**ICIM**



0425

# Attestato di Esame CE del Tipo EC-Type Examination Certificate

Certificato N. **0425 15 ATEX 002822\_00 X**  
 Certificate N.

In conformità a quanto prescritto dall'Art.8 par.1 lettera a) della Direttiva 94/9/CE  
 In compliance to what prescribed by the Art.8 par.1 letter a) of the Directive 94/9/CE

ORGANISMO NOTIFICATO / NOTIFIED BODY

**ICIM S.p.A. - Identification number: 0425**  
 Piazza Don Enrico Mapelli, 75 - 20099 Sesto San Giovanni (MI) - ITALY

DATI FABBRICANTE / MANUFACTURER DETAILS

**SPIRAX SARCO S.r.l.**  
 Via per Cinisello, 18  
 20834 NOVA MILANESE (MB)

DATI PRODOTTO / PRODUCT DETAILS

MODELLO / MODEL **Posizionatore Elettropneumatico**  
 CARATTERISTICHE DEL MODELLO **EP500**  
 CHARACTERISTICS OF THE MODEL  
 CLASSIFICAZIONE / CLASSIFICATION **Vedi Allegato / See Annex**

EVENTUALI ESTENSIONI / EXTENSIONS

II

ESAME CE DEL TIPO / EC TYPE EXAMINATION

L'esame è stato eseguito sul prodotto e sul Fascicolo Tecnico della Costruzione così identificato: RDS002 REV.1  
 EC Type Examination has been conducted on product and relative Technical Construction File code RDS002 REV.1

CON ESITO / WITH RESULT

**POSITIVO / POSITIVE**

ATTESTATI DI PROVA / TEST REPORTS

EUT.14 ATEX.0448/52553

NOTE / NOTES

Rimane responsabilità del fabbricante dimostrare conformità ad altre Direttive applicabili al prodotto oggetto di questo certificato  
 It remains the responsibility of the manufacturer to demonstrate conformity with other Directives applicable to the product described in this certificate.

Questo attestato è valido solo se gli esemplari sono identici ai modelli sopra indicati. Eventuali modifiche tecniche devono essere dichiarate ad ICIM che comunicherà come procedere / This certificate is valid only for the models above specified. Any technical change must be declared to ICIM S.p.A. that will give information how to proceed

Il presente Certificato è da ritenersi valido solo se accompagnato dal relativo Allegato / This Certificate is valid only with the relative Annex

ICIM S.p.A.

0080CERT\_00\_IT

15/09/2015

PRIMA EMISSIONE  
 FIRST ISSUE

15/09/2015

EMISSIONE CORRENTE  
 CURRENT ISSUE

14/09/2025

DATA DI SCADENZA  
 EXPIRING DATE

ICIM S.p.A. a socio unico - Piazza Don Enrico Mapelli, 75 - 20099 Sesto San Giovanni (MI)



ISO 9001 A    ISO 9001 G  
 ISO 9001 D    ISO 9001 E  
 ISO 9001 F    ISO 9001 E  
 ISO 9001 C    ISO 9001 H

Member degli Accordi di Mutuo Riconoscimento EA, IAF e ILAC  
 Signatory of EA, IAF and ILAC Mutual Recognition Agreements



**ICIM**



0425

## Attestato di Esame CE del Tipo EC-Type Examination Certificate

ALLEGATO / ANNEX

Certificato N.  
 Certificate N.

**0425 15 ATEX 002822\_00 X**

MODELLI MODELS	EP500
CARATTERISTICHE DEL MODELLO CHARACTERISTICS OF THE MODEL	Posizionatore Elettropneumatico
CLASSIFICAZIONE CLASSIFICATION	II2G Ex d mb IIC T6 Gb -20°C≤Tas+ 75°C II2D Ex tb mb IIIC T 76°C Db -20°C≤Tas+ 75°C II2G Ex ia IIC T6 Gb -20°C≤Tas+ 75°C II2D Ex ia IIIC T 76°C Db -20°C≤Tas+ 75°C
NORME DI RIFERIMENTO REFERENCE STANDARDS	EN 60079-0:2012 EN 60079-1:2007 EN 60079-11:2012 EN 60079-18:2009 EN 60079-31:2009
DOCUMENTI LISTATI SCHEDULED DOCUMENTS	RDS002 REV.1 del 07/09/2015
*X* CONDIZIONI SPECIALI PER UN UTILIZZO SICURO	Nella versione a sicurezza intrinseca, la categoria "ia" evidenzia la possibilità di installare l'apparecchio in un sistema di categoria "ia", senza degradarne il livello di sicurezza. L'apparecchio non può essere installato in zona 0 né in zona 20.

ICIM S.p.A.

15/09/2015

PRIMA EMISSIONE  
FIRST ISSUE

15/09/2015

EMISSIONE CORRENTE  
CURRENT ISSUE

14/09/2025

DATA DI SCADENZA  
EXPIRING DATE

ICIM S.p.A. a socio unico - Piazza Don Enrico Mapelli, 75 - 20098 Sesto San Giovanni (MI)

0068CERT\_00\_IT



552 N° 004 A    532 N° 008 D  
 554 N° 005 D    534 N° 004 D  
 553 N° 005 F    531 N° 006 B  
 555 N° 002 C    536 N° 005 H

Membro degli Accordi di Mutuo Riconoscimento EA, IAF e ILAC  
 Signatory of EA, IAF and ILAC Mutual Recognition Agreements



**ICIM**



0425

## Attestato di Esame CE del Tipo EC-Type Examination Certificate

ALLEGATO / ANNEX

Certificato N. **0425 15 ATEX 002822\_00 X**  
 Certificata N.

DOCUMENTI CONSEGNATI (FASCICOLO TECNICO) DOCUMENTATION DELIVERED (TECHNICAL FILE)		
DESCRIZIONE DESCRIPTION	NUMERO E REVISIONE NUMBER AND REVISION	DATA DATE
DESCRIZIONE GENERALE DEL TIPO GENERAL TYPE DESCRIPTION	RDS002 REV.1 – CAP.1	07-09-2015
DISEGNI DI PROGETTAZIONE E FABBRICAZIONE, SCHEMI DI COMPONENTI, SOTTOUNITÀ, CIRCUITI ETC. DESIGN AND MANUFACTURING DRAWING AND LAYOUTS OF COMPONENTS, SUB-ASSEMBLIES, CIRCUITS, ETC.	RDS002 REV.1 – CAP.3 e 4	07-09-2015
DESCRIZIONE E SPIEGAZIONI NECESSARIE ALLA COMPRESIONE DI TALI DISEGNI E SCHEMI E AL FUNZIONAMENTO DEL PRODOTTO DESCRIPTION AND EXPLANATIONS NECESSARY FOR THE UNDERSTANDING OF SAID DRAWING AND LAYOUTS AND THE OPERATION OF THE PRODUCT	RDS002 REV.1 – CAP.3 e 4	07-09-2015
RISULTATI DEI CALCOLI DI PROGETTO E DEGLI ESAMI RESULTS OF DESIGN CALCULATIONS MADE, EXAMINATIONS CARRIED OUT	RDS002 REV.1 – CAP.6	07-09-2015
ELENCO DELLE NORME APPLICATE E DESCRIZIONE DELLE SOLUZIONI ADOTTATE PER SODDISFARE I REQUISITI DI SICUREZZA LIST OF THE STANDARDS REFERRED TO IN ARTICLE 5, ALLIED IN FULL	RDS002 REV.1 – CAP.5	07-09-2015
RAPPORTI SULLE PROVE EFFETTUATE TEST REPORTS	RDS002 REV.1 – All.2.2	07-09-2015
MANUALE D'USO MANUAL	RDS002 REV.1 – Cap.10	07-09-2015
ANALISI DI RISCHIO RISK ANALYSIS	RDS002 REV.1 – Cap.11	07-09-2015
DICHIARAZIONE CE DI CONFORMITÀ EC DECLARATION OF CONFORMITY	RDS002 REV.1 – All.14.1	07-09-2015

ICIM S.p.A.

15/09/2015	15/09/2015	14/09/2025
PRIMA EMISSIONE FIRST ISSUE	EMISSIONE CORRENTE CURRENT ISSUE	DATA DI SCADENZA EXPIRING DATE

ICIM S.p.A. a socio unico - Piazza Don Enrico Mapelli, 75 - 20099 Sesto San Giovanni (MI)

0099CERT\_00\_17

